

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
01/08/2016	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
01/08/2016	MPLHEQCR416	14T Franna Crane
29/11/2014	MPLHEQCR416	14T Franna Crane
29/11/2014	MPLHEQCR416	14T Franna Crane
15/10/2014	MPLHEQCR416	14T Franna Crane
04/09/2014	MPLHEQCR416	14T Franna Crane
03/09/2014	MPLHEQCR416	14T Franna Crane
03/09/2014	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
	MPLHEQCR416	14T Franna Crane
04/07/2014	MPLHEQCR416	14T Franna Crane
02/05/2014	MPLHEQCR416	14T Franna Crane

WO Description

Jump start battery
PMS-EXT-MPL-HEQCR-52W
PMS-MBM-MPL-HEQCR-52W
Aircon Not Cooling
PMS-MBM-MPL-HEQCR-52W
PM Change Request
Replace steer pins and bushes
Repair articulation exceeds
Repair play in boom pivots
Defects from 12monthly inspect
Attend to Unit 334 Battery
Replace LHF tyre
BOOM CLEARANCE LIGHT RIGHT SID
WINDSCREEN LEAKING AND CAB RUS
INSPECT 416 CRANE ARTICULATION
MIRRORS NEED TO BE TIGHTENED.
CRANE 416 MIRRORS LOOSE
CRANE 416 TIGHTEN MIRRORS
Hydraulic oil leak
Lubricate wire rope on crane
FIRE EXTINGUISHER OUT OF DATE
SMALL LEAK IN BOTTOM OF HYDRAU
ARRANGE YEARLY ROADWORTHY
LEAK IN HYDRAULIC TANK
CONSTANTLY LOOSING AIR - HORN
500HR Service and Inspection
HYD OIL LEVEL LOW
Repair/reseal front box
Replace rear clearance light
Repair drivers side mirror
Replace 2 way handpiece
Replace Transfer Case input
Evident Play in steer pins/bea
Tighten up ignition switch
Adjust tyre pressures
Repair wiper washers not worki
Adjust boom pivots
Adjust boom extend/retract rop
LEFT SIDE LIGHT ON THE LIFT CY
NO REAR VIEW MIRROR
CHECK FUNCTIONALITY OF EMERGEN
Replace fan hub block and bear
Repair leaking radiator
Fit up grease bank to crane
Fit up reversing camera
REMOVE AND REPLACE HEADLIGHT S
Replace Air Horn

Fit solar panel to crane
MAIN LIGHT SWITCH FAULTY ONLY
CHECK WINDSCREEN FOR LEAKAGE A
Replace Hyd coupling
Fan Coupling Missing Bolts
NOISE AT CENTRE PIN
Replace Key Start Switch
ROBWAY NOT CALLIBRATING
CHECK FUNCTIONALITY AS PER DIS
FRANNA 416 ENGINE TEMP GAUGE N
250HR Service and Inspection
Buzzer constantly going off
Repair Robway fault
Replace swivel hook
FUEL UP CRANE
INSPECT REPAIR OIL LEAK
CRANE 416 HAS AN OIL LEAK ON T
OIL LEAK ON LINE TO WINCH DRUM
Replace Steel Pipe Tele Ram
LEFT HAND MIRROR BROKEN
FLASHING LIGHT NOT WORKING
Replace Both Door Handle Assem
COOLANT LEAKING
JUMP START CRANE
ARRANGE YEARLY ROADWORTHY
PLEASE INSPECT CRANE MAST AFTE
Replace damaged front LHS
WINDSCREEN WIPER SWITCH BROKEN
BROKEN FAN BELT
Replace bonnet strut
Replace mirrors
Replace headlight switch
BONNET HARD TO LIFT STANDING B
NO THREE POINTS OF CONTACT WHE
ROTARY LIGHT SWITCH IN CAB HAS
MIRROR BRACKETS RUSTED OUT BOT
Fit up handles to bonnet
Re-seal transfer case input
Replace Batteries
Replace RH Steer cylinder
REAR WORKLIGHT SWITCH BROKEN
RUBBER BUMP STOP FOR LEFT HAND
INTERIOR LIGHT INADEQUATE FOR
2000 Hr Service and Inspection
Memory stick for manuals
BROKEN HINGE ON GATE AIR CLEAN
ROB VERNER ASSISTANCE WITH BRO
FIRE EXSTINGUISHER OUT OF DATE

DASH LIGHTS NOT WORKING
LH CLEARANCE LIGHT MISSING
LOW AIR BUZZER ACTIVATING AFTE
LOW BEAM HEADLIGHT RIGHT HAND
CR416 Requires Full Inspect
CRANE 416 DOOR RUBBERS OR ROO
Ignition switch loose
Check and adjust tyre pressure
Repair wiper washers not worki
Adjust boom Pivots
Adjust boom extend/retract rop
Update fire extinguisher
Fit manual extension bar
Replace boom pivot pins and
Defects from 12 monthly
RODWAY NEEDS TO BE OVERRIDDEN
LEFT HAND CLEARANCE LIGHT MISS
IGNITION KEY BARREL LOOSE
L/H RAM SIDE LIGHT MISSING / R
CAN WE GET DASH LIGHTS FIXED A
AIR CONDITIONING NOT WORKING A
LHS WIDTH LIGHT MISSING
ADJUST SCREEN SETTINGS
R/H REAR INDICATOR TAIL LIGHT
CRANE 416 RH FRONT AND BOOM CL
CRANE 416 FIRE EXTINGUISHER EX
CRANE 416 RIGHT REAR INDERCATO
CRANE AIR LEAK AND LOOSE SWITC
CABIN LIGHT NOT WORKING
CRANE 416 CLEARANCE LIGHT MISS
Replace Lift cylinders
ARRANGE YEARLY ROADWORTHY
Repace leaking Transfer case s
250 Hr Service and Inspection
REPLACE FAULTY ROBWAY DEVICE
ROBWAY NOT WORKING (ALARMING A
REPAIR BROKEN DOOR LATCH
ADDRESS DEFECTS AS PER INSPECT
Repair Robway fault
Adjust wire cable
Adjust boom Pivots
NO PULL WIRE ON REAR AIR TANK
Repair leak on RH steer cylind
Adjust boom pivots
Adjust boom extend/retract rop
Replace steer pins and bushes
Manual extension bar bent
Robway system playing up

CRANE AIR CON NOT GETTING COLD
RHS PARKING LIGHT NOT WORKING
CRANE 416, ROBWAY FAULTING
REAR RHS INDICATOR NOT WORKIN
CRANE 416 LHS REVERSE LIGHT NO
AIR LEAK
CRANE 416 TAKE LONG TIME TO BU
REPLACE INTERIOR LIGHT
WIRE HANGING FROM BOOM
CRANE ROBWAY SYSTEM
WIRE ROPE NOT TRACKING CENTRE
NO BOOM FUNCTIONS
Fit rear handrails
Repair oil leak
500 Hr Service and Inspection
Fit up temp scaffolding
CRANE ON WHARF FLAT BATTERIE
INSPECT WINCH
JUMP START THE FRANNA CRANE.
DAMAGE TO LH REAR TYRE
ARRANGE YEARLY ROADWORTHY
ENGINE STOP HAND CABLE REALLY
REPLACE CRACKED MIRROR ON RIGH
RIGHT HAND SIDE MIRROR BROKEN
STOP MACHINE HANDLE IN CAB, ON
REPLACE RIGHT HAND MIRROR AND
JUMP START
LOW HYD. OIL
WORKLIGHTS NOT WORKING
High/Low travel linkage broken
CRANE 416 R/H SIDE MIRROR GLAS
REAR AIR TANK DRAIN LINE MISSI
ENGINE OIL OVERFULL
RIGHT HAND MIRROR CRACKED
REAR AIR DRAIN CABLE MISSING
HOLDING BRAKE NOT WORKING
R/H/R tyre damaged
DRIVERS SIDE MIRROR CRACKED
PUSH BAR ON FLY JIB BENT
DRIVERS SIDE MIRROR SIEZED AND
RIGHT HAND MIRROR GLASS BROKEN
CRANE 416 - R/H MIRROR CRACKED
CHECK AIR LEAK ON CRANE 416
REPLACE BLOWN RIGHT REAR TYRE
MULTIPLE FAULTS LISTED IN TEXT
Repair flashing light not work
Adjust boom pivots
Adjust boom extend/retract

Replace steer pins and bushes
Lube 1st section of boom slide
Replace pre cleaner
Replace fuel pump and filter
DRIVERS SIDE REAR VIEW MIRROR
Replace pilot lights behind
Replace Transfer output shaft
Replace angle indicator
BAD OIL LEAK UNDER THE BRAKE P
250 hr Service and Inspection
PLEASE REPLACE DAMAGED REAR VI
Replace revolving light
HOOK WONT SWIVEL
DRIVERS SIDE DOOR HANDLE BROKE
RIGHT SIDE MIRRIOR BROKEN ON C
FAN BELTS REQUIRE ADJUSTMENT.
OIL LEAK UNDER STEERING WHEEL
WINDSCREEN WASHER NOT WORKING
R/H LOW BEAM NOT WORKING
Investigate no reverse
ENGINE OIL REPORTED OVER FULL
OIL PRESSURE SENDER WIRE BROKE
CLEARANCE LIGHT ON BOOM BROKEN
Inspect RHR tyre side wall
CRANE 416 FRONT WORK LIGHTS DU
FLAT BATTERIES - JUMP STARTED
ENGINE COWLING STRUTS NEED REP
CRANE OVERLOAD ALARM COMES ON
BAD AIR LEAK. NO AIR IN TANKS
ARRANGE YEARLY ROADWORTHY
REAR WORKING LIGHT OBSTRUCTS F
1000 Hr Service and Inspection
REPLACE ENGINE COVER STRUT - V
CRANE O/LOAD LIGHT COMING ON W
REPAIRS AS PER INSPECTION SHEE
RADIATOR NEEDS WATER AND AIR C
RHS BOOM LIGHT & LHS REAR LIGH
RIGHT HAND BOOM WORK LIGHT NOT
MELTED THROTTLE CABLE
Reseal transfer case output
TOP UP HYDRAULIC OIL
Repair ac system
PLEASE REPAIR FAULTS AS LISTED
BOOM OVERLOAD WARNING LIGHT ST
HYD TANK LOW ON OIL
Control levers to be replaced
No 2-way
Replace boom lenght indicator

Repair horn
Replace governor valve
Robway alarm going off
250HR SERVICE UNIT416 CRANE
Fan Belt squealing
3 X CLEARANCE LIGHTS NOT WORKI
NO HYD
ARRANGE YEARLY ROADWORTHY
RH BRAKE LIGHT NOT WORKING, EM
Emergency steering update
R/H LOW BEAM NOT WORKING. FAN
HYDRAULIC AND TRANSMISSION OIL
AIR LEAK WHEN APPLYING 4WD SEL
Repair pos 2 tyre
CRANE WONT START
CRANE BOGGED ON S/P2282, MAJOR
Card Reader US Intermittent
START CRANE
EMERGENCY STEERING DOES NOT WO
AIR LEAK WHEN SWITCHED OFF
REPLACE BATTERIES
REPAIR DAMAGED ELECTRICAL WIR
Replace air compressor
416 HAS A AIR LEAK OR HAS PROB
500 Hr Service and Inspection
BAD AIR LEAK TAKES A LONG TIME
FLASHING LIGHT NOT WORKING
RIGHT HAND SIDE OF MOTOR FUEL
Replace leaking hose
ARRANGE YEARLY ROADWORTHY
CRANE WONT START
LOAD CHART IN CAB RESTRICTING
CRANE NOT HOLDING AIR PRESSURE
REPAIR AIR LEAK
AIR LEAK
REPAIR MULTIPLE FAULTS AS LIST
10 Yearly Inspection
Replace ignition barrel
PRE FILTER BOWL CRACKED FILLS
Repair flat tyre Inner RHS fr
Repairs from 12 monthly servic
BRAKE AND REVERSE LIGHT WIREIN
STARTER FAULT
Replace starter motor
250 Hr service and Inspection
Repair air leak
Replace exhaust tip
FILL CRANE 416 WITH DIESEL

416 AIRCON NOT WORKING
REPLACE INTERIOR LIGHT INSIDE
DAMAGED TAIL LIGHT, R.H.S.
HEAD LIGHTS AS WELL AS VARIOUS
RIGHT HAND SIDE HEAD LIGHT NOT
REPAIR LEFT HAND SIDE SIDE LIG
Replace winch rope anchor pin
ARRANGE YEARLY ROADWORTHY
Repair fuel leak
Replace manual extension pins
2000 Hr Service and Inspection
HYDRAULIC FAULT
INSPECT FORIEGN OBJECT CAUGHT
HOLDING BRAKE NOT WORKING
FUEL LEAK AND AIR CON BELT
FUEL FILTER LEAKING
416 AIR CON NOT WORKING
FIRE EXTINGUISHER OUT OF DATE
REAR LEFT HAND BLINKER NOT WOR
FUEL LEAK AT FILTER AREA.
AIR CON NOT WORKING. BELT MISS
SPEEDO NOT WORKING
crane 416 blowing hot air
TIGHTEN ALTERNATOR BELT
ARRANGE YEARLY ROADWORTHY
CLEARANCE LIGHT COVER MISSING
LEFT HAND SIDE REAR INDICATOR
ELECTRICAL FAULT, POWER SUPPLY
IGNITION STAYS ON WHEN KEY IS
FIRE EXTINGUISHER OUT OF DATE
FAN BELTS LOOSE
250 Hr Service and Inspection
Repair no drive
RELOCATE OVERHEAD CRANE FROM C
Noise in transfer case, will n

Description 2

JUMP START BATTERY
ANNUAL CRANE INSPECTION
ANNUAL CRANE INSPECTION
AIRCON NOT COOLING
ANNUAL CRANE INSPECTION
PM CHANGE REQUEST #1876265 - DELETE MODEL PM 20721 & ADD NEW PM
FROM 12 MONTHLY
1 MM- FROM 12 MONTHLY
FROM 12 MONTHLY
DEFECTS FROM 12MONTHLY INSPECT
BATTERY JUMP START - MPLLVFPV334
SIDE WALL DAMAGE
BOOM CLEARANCE LIGHT RIGHT SIDE NOT WORKING, COOLANT LOW CHECK FOR LEAKS
WINDSCREEN LEAKING AND CAB RUSTING.
INSPECT 416 CRANE ARTICULATIONS
MIRRORS NEED TO BE TIGHTENED.
CRANE 416 MIRRORS LOOSE
CRANE 416 TIGHTEN MIRRORS
HYDRAULIC OIL LEAK- 8/9/22 COMPLETE
LUBRICATE WIRE ROPE ON CRANE
FIRE EXTINGUISHER OUT OF DATE
SMALL LEAK IN BOTTOM OF HYDRAULIC TANK COMPLETE
ARRANGE YEARLY ROADWORTHY
LEAK IN HYDRAULIC TANK
HORN/SOLENOID REQUIRE REPLACING- SEE ATTACHED
500HR SERVICE AND INSPECTION
WORK COMPLETE 03/05/22
REPAIR/RESEAL FRONT BOX
LENS MISSING/BROKEN
ARM BROKEN
REPLACE 2 WAY HANDPIECE
COMPLETE 28/02/22
COMPLETE 28/02/22
TIGHTEN UP IGNITION SWITCH
ADJUST TYRE PRESSURES
REPAIR WIPER WASHERS NOT WORKI
ADJUST BOOM PIVOTS
ES
LEFT SIDE LIGHT ON THE LIFT CYLINDER NOT WORKING
NO REAR VIEW MIRROR
COMPLETE
ING
REPAIR LEAKING RADIATOR
FIT UP GREASE BANK TO CRANE
COMPLETE 28/02/22
REMOVE AND REPLACE HEADLIGHT SWITCH
REPLACE AIR HORN

FIT SOLAR PANEL TO CRANE
MAIN LIGHT SWITCH FAULTY ONLY WORKS INTERMITTENTLY
CHECK WINDSCREEN FOR LEAKAGE AS DASH ALL WET
REPLACE HYD COUPLING
FAN COUPLING MISSING BOLTS
NOISE AT CENTRE PIN
REPLACE KEY START SWITCH
SEE ATTACHMENT FOR NOTES
CHECK FUNCTIONALITY AS PER DISCUSSION
FRANNA 416 ENGINE TEMP GAUGE NOT WORKING
250HR SERVICE AND INSPECTION
UNDER DASH
ALARMING AT 80%
REPLACE SWIVEL HOOK
FUEL UP CRANE
INSPECT REPAIR OIL LEAK
CRANE 416 HAS AN OIL LEAK ON THE WINCH DRUM
OIL LEAK ON LINE TO WINCH DRUM
REPLACE STEEL PIPE TELE RAM
LEFT HAND MIRROR BROKEN
FLASHING LIGHT NOT WORKING
REPLACE BOTH DOOR HANDLE ASSEM
COOLANT LEAKING
JUMP START CRANE
ARRANGE YEARLY ROADWORTHY
PLEASE INSPECT CRANE MAST AFTER CONTACT WITH 15M BROW.
TYRE
WINDSCREEN WIPER SWITCH BROKEN, MIRROR STAY BROKEN, FAN BELT MISSING, LHS TYRE
BROKEN FAN BELT
SEE NOTES
REPLACE MIRRORS
SEE ATTACHMENT
BONNET HARD TO LIFT STANDING BESIDE WITH HANDLE AT FRONT, BODY ERGONOMICS
NO THREE POINTS OF CONTACT WHEN ACCESSING BACK OF CRANE.
ROTARY LIGHT SWITCH IN CAB HAS BEEN BROKEN OFF, NEEDS REPLACING
MIRROR BRACKETS RUSTED OUT BOTH SIDES, NEED REPLACING
FIT UP HANDLES TO BONNET
RE-SEAL TRANSFER CASE INPUT
REPLACE BATTERIES
REPLACE RH STEER CYLINDER
REAR WORKLIGHT SWITCH BROKEN
RUBBER BUMP STOP FOR LEFT HAND SIDE FRONT BOX LID MISSING
INTERIOR LIGHT INADEQUATE FOR NIGHT TIME VISION
2000 HR SERVICE AND INSPECTION
MEMORY STICK FOR MANAULS
BROKEN HINGE ON GATE AIR CLEANER SIDE .CRANE 416
ROB VERNER ASSISTANCE WITH BROW RIGGING AND JSA
FIRE EXSTINGUISHER OUT OF DATE

DASH LIGHTS NOT WORKING
LH CLEARANCE LIGHT MISSING
LOW AIR BUZZER ACTIVATING AFTER OPERATING.
LOW BEAM HEADLIGHT RIGHT HAND SIDE NOT WORKING
DEFECTS TO BE RECTIFIED
CRANE 416 DOOR RUBBERS OR ROOF LEAKING WATER ONTO THE D/S FLOOR AFTER RAIN
IGNITION SWITCH LOOSE
S
ING
ADJUST BOOM PIVOTS
ES
UPDATE FIRE EXTINGUISHER
FIT MANUAL EXTENSION BAR
BEARINGS
DEFECTS FROM 12 MONTHLY
RODWAY NEEDS TO BE OVERRIDDEN CONTINUALLY - PLEASE CHECK.
LEFT HAND CLEARANCE LIGHT MISSING
IGNITION KEY BARREL LOOSE
L/H RAM SIDE LIGHT MISSING / R/H LOW BEAM NOT WORKING /NO DASH LIGHTS
CAN WE GET DASH LIGHTS FIXED AND DECENT INTERIOR LIGHT FITTED
AIR CONDITIONING NOT WORKING AND GETTING COLD
LHS WIDTH LIGHT MISSING
ADJUST SCREEN SETTINGS
R/H REAR INDICATOR TAIL LIGHT LENSE CRACKED
CRANE 416 RH FRONT AND BOOM CLEARANCE LIGHTS BOTH FAILED
CRANE 416 FIRE EXTINGUISHER EXPIRED
CRANE 416 RIGHT REAR INDERCATOR CRACKED
CRANE AIR LEAK AND LOOSE SWITCH
CABIN LIGHT NOT WORKING
CRANE 416 CLEARANCE LIGHT MISSING
REPLACE LIFT CYLINDERS
ARRANGE YEARLY ROADWORTHY
EALS INPUT AND OUTPUT
250 HR SERVICE AND INSPECTION
REPLACE FAULTY ROBWAY DEVICE AND INSTALL TRAFFIC LIGHTS TO BONNET
ROBWAY NOT WORKING (ALARMING ALL THE TIME)
REPAIR BROKEN DOOR LATCH
ADDRESS DEFECTS AS PER INSPECTION SHEETS SENT TO MOBILE PLANT
SEE ATTACHMENTS
ADJUST WIRE CABLE
ADJUST BOOM PIVOTS
NO PULL WIRE ON REAR AIR TANK
REPAIR LEAK ON RH STEER CYLIND
ADJUST BOOM PIVOTS
ADJUST BOOM EXTEND/RETRACT ROP
REPLACE STEER PINS AND BUSHES
SEE ATTACHMENTS
SEE ATTACHMENTS

CRANE AIR CON NOT GETTING COLD
RHS PARKING LIGHT NOT WORKING
CRANE 416, ROBWAY FAULTING
REAR RHS INDICATOR NOT WORKING. LENS IS DULL
CRANE 416 LHS REVERSE LIGHT NOT WORKING
AIR LEAK
CRANE 416 TAKE LONG TIME TO BUILD UP AIR PRESSURE
REPLACE INTERIOR LIGHT
WIRE HANGING FROM BOOM
CRANE ROBWAY SYSTEM
WIRE ROPE NOT TRACKING CENTRE OF BOOM
NO BOOM FUNCTIONS
FIT REAR HANDRAILS
REPAIR OIL LEAK
500 HR SERVICE AND INSPECTION
FIT UP TEMP SCAFFOLDING
CRANE ON WHARF FLAT BATTERIE
INSPECT WINCH
JUMP START THE FRANNA CRANE.
DAMAGE TO LH REAR TYRE
ARRANGE YEARLY ROADWORTHY
ENGINE STOP HAND CABLE REALLY STIFF AND T PIECE IS BROKEN .
REPLACE CRACKED MIRROR ON RIGHT SIDE
RIGHT HAND SIDE MIRROR BROKEN
STOP MACHINE HANDLE IN CAB, ONE SIDE BROKEN (REPLACE)
REPLACE RIGHT HAND MIRROR AND FIT STRAP ON DOOR TO RESTRICT OPENING
JUMP START
LOW HYD. OIL
WORKLIGHTS NOT WORKING
HIGH/LOW TRAVEL LINKAGE BROKEN
CRANE 416 R/H SIDE MIRROR GLASS BROKEN
REAR AIR TANK DRAIN LINE MISSING
ENGINE OIL OVERFULL
RIGHT HAND MIRROR CRACKED
REAR AIR DRAIN CABLE MISSING
HOLDING BRAKE NOT WORKING
R/H/R TYRE DAMAGED
DRIVERS SIDE MIRROR CRACKED
PUSH BAR ON FLY JIB BENT
DONE
RIGHT HAND MIRROR GLASS BROKEN & FRAME DAMAGED
CRANE 416 - R/H MIRROR CRACKED, LIFT RAMS SEALS WEAVING, COWLING STRUTS WEAK.
CHECK AIR LEAK ON CRANE 416
REPLACE BLOWN RIGHT REAR TYRE & DAMAGED RIM
MULTIPLE FAULTS LISTED IN TEXT BOX BELOW
REPAIR FLASHING LIGHT NOT WORK
ADJUST BOOM PIVOTS
ROPES

REPLACE STEER PINS AND BUSHES
LUBE 1ST SECTION OF BOOM SLIDE
ORDER ON ANOTHER W/O 85113
HOUSING
DRIVERS SIDE REAR VIEW MIRROR GLASS IS MISSING.
DASH
REPLACE TRANSFER OUTPUT SHAFT
REPLACE ANGLE INDICATOR
BAD OIL LEAK UNDER THE BRAKE PEDAL.
250 HR SERVICE AND INSPECTION
PLEASE REPLACE DAMAGED REAR VIEW MIRRORS.
AND LIFT HIGHT THAN THE REVERSE LIGHT
HOOK WONT SWIVEL
DRIVERS SIDE DOOR HANDLE BROKEN
RIGHT SIDE MIRRIOR BROKEN ON CRANE, REPLACE
FAN BELTS REQUIRE ADJUSTMENT. FIRE EXTINGUISHER OUT OF DATE.
OIL LEAK UNDER STEERING WHEEL
WINDSCREEN WASHER NOT WORKING
R/H LOW BEAM NOT WORKING
BUZZER OR LIGHTS
ENGINE OIL REPORTED OVER FULL
OIL PRESSURE SENDER WIRE BROKEN
CLEARANCE LIGHT ON BOOM BROKEN
OCEAN TYRES TO INSPECT
CRANE 416 FRONT WORK LIGHTS DULL, CHANGE TO LED PLEASE
FLAT BATTERIES - JUMP STARTED.
ENGINE COWLING STRUTS NEED REPLACING. UNABLE TO ACCESS ENGINE BAY TO AVOID INJUR
CRANE OVERLOAD ALARM COMES ON
BAD AIR LEAK. NO AIR IN TANKS WHEN STARTING UP.
ARRANGE YEARLY ROADWORTHY
REAR WORKING LIGHT OBSTRUCTS FLASHING WARNING LIGHT.
1000 HR SERVICE AND INSPECTION
REPLACE ENGINE COVER STRUT - VERY HEAVY FOR THE OPERATOR TO LIFT.
CRANE O/LOAD LIGHT COMING ON WITH THE JIB EXTENDED.
REPAIRS AS PER INSPECTION SHEET
RADIATOR NEEDS WATER AND AIR CON BELTS ARE LOOSE
RHS BOOM LIGHT & LHS REAR LIGHT NOT WORKING
RIGHT HAND BOOM WORK LIGHT NOT WORKING
MELTED THROTTLE CABLE
SEAL
TOP UP HYDRAULIC OIL
REPAIR AC SYSTEM
PLEASE REPAIR FAULTS AS LISTED BELOW
BOOM OVERLOAD WARNING LIGHT STAYING ON
HYD TANK LOW ON OIL
WITH ORIGINAL BENT TYPE
NO 2-WAY
REPLACE BOOM LENGHT INDICATOR

REPAIR HORN
AIR LEAKING
OVERLOAD SWITCH U/S
FRANNA AT-14
FAN BELT SQUEALING
3 X CLEARANCE LIGHTS NOT WORKING
NO HYD
ARRANGE YEARLY ROADWORTHY
RH BRAKE LIGHT NOT WORKING, EMERGENCY STEERING PUMP NOT WORKING
CAMPAIGN BULLETING
R/H LOW BEAM NOT WORKING. FAN BELTS NEED ADJUSTING
HYDRAULIC AND TRANSMISSION OIL LOW
AIR LEAK WHEN APPLYING 4WD SELECTOR
REPAIR POS 2 TYRE
CRANE WONT START
CRANE BOGGED ON S/P2282, MAJOR AIR LEAK
FAULT
START CRANE
EMERGENCY STEERING DOES NOT WORK (THE CRANE HAS BEEN TAGGED OUT)
AIR LEAK WHEN SWITCHED OFF
REPLACE BATTERIES
REPAIR DAMAGED ELECTRICAL WIRES ON BOOM
REPLACE AIR COMPRESSOR
416 HAS A AIR LEAK OR HAS PROBLEMS PUMPING UP AIR FOR BRAKES
500 HR SERVICE AND INSPECTION
BAD AIR LEAK TAKES A LONG TIME TO PUMP UP AIR PRESSURE
FLASHING LIGHT NOT WORKING
RIGHT HAND SIDE OF MOTOR FUEL LINE STARTING TO CRACK
REPLACE LEAKING HOSE
ARRANGE YEARLY ROADWORTHY
CRANE WONT START
LOAD CHART IN CAB RESTRICTING VISION
CRANE NOT HOLDING AIR PRESSURE
REPAIR AIR LEAK
AIR LEAK
REPAIR MULTIPLE FAULTS AS LISTED BELOW
10 YEARLY INSPECTION
REPLACE IGNITION BARREL
PRE FILTER BOWL CRACKED FILLS WITH WATER CHECK STOP LIGHTS AND WORKING LIGHTS
REPAIR FLAT TYRE INNER RHS FR
REPAIRS FROM 12 MONTHLY SERVICE
BRAKE AND REVERSE LIGHT WIRING NEEDS ATTENTION
STARTER FAULT
REPLACE STARTER MOTOR
2000 HR SERVICE AND INSPECTION
REPAIR AIR LEAK
REPLACE EXHAUST TIP
FILL CRANE 416 WITH DIESEL

416 AIRCON NOT WORKING
REPLACE INTERIOR LIGHT INSIDE CAB TO ENABLE TO SEE IGNITION KEY
DAMAGED TAIL LIGHT, R.H.S.
HEAD LIGHTS AS WELL AS VARIOUS WORK LIGHTS AND BOOM LIGHTS NOT WORKING.
RIGHT HAND SIDE HEAD LIGHT NOT WORKING
REPAIR LEFT HAND SIDE SIDE LIGHTS
REPLACE WINCH ROPE ANCHOR PIN
ARRANGE YEARLY ROADWORTHY
BLEED SCREW
REPLACE MANUAL EXTENSION PINS
2000 HR SERVICE AND INSPECTION
HYDRAULIC FAULT
INSPECT FORIEGN OBJECT CAUGHT BETWEEN FRONT DUALS
HOLDING BRAKE NOT WORKING
FUEL LEAK AND AIR CON BELT
FUEL FILTER LEAKING
416 AIR CON NOT WORKING
FIRE EXTINGUISHER OUT OF DATE
REAR LEFT HAND BLINKER NOT WORKING
FUEL LEAK AT FILTER AREA.
AIR CON NOT WORKING. BELT MISSING.
SPEEDO NOT WORKING
AIR CONDITONER BLOWING AIR BUT NOT COLD
TIGHTEN ALTERNATOR BELT.
ARRANGE YEARLY ROADWORTHY
CLEARANCE LIGHT COVER MISSING ON LEFT HAND SIDE BOOM
LEFT HAND SIDE REAR INDICATOR NOT WORKING
ELECTRICAL FAULT, POWER SUPPLY
IGNITION STAYS ON WHEN KEY IS REMOVED
FIRE EXTINGUISHER OUT OF DATE
FAN BELTS LOOSE
250 HR SERVICE AND INSPECTION
REPAIR NO DRIVE
RELOCATE OVERHEAD CRANE FROM COTTON SEED AREA
NOISE IN TRANSFER CASE, WILL N

Actual Finish Date

19/10/2025
20/10/2025
24/01/2025
09/01/2024
04/07/2024
26/05/2023
28/03/2023
15/03/2023
05/12/2023
05/12/2023
22/02/2023
24/01/2023
08/03/2023
05/12/2023
14/11/2022

26/09/2022
08/09/2022
06/09/2022
31/08/2022
04/07/2022
06/02/2023
31/08/2022
04/09/2022
01/09/2022
03/05/2022
16/03/2022
29/03/2022
29/03/2022
16/03/2022
01/03/2022
01/03/2022
24/01/2022
17/02/2022
28/01/2022
01/02/2022
17/02/2022
18/01/2022
18/01/2022
04/01/2022
30/12/2021
24/12/2021
02/03/2022
01/03/2022
01/12/2021
08/12/2021

09/02/2022
09/12/2021
08/12/2021
12/01/2022
14/10/2021
02/03/2022
28/09/2021
12/01/2022
23/08/2021
10/08/2021
17/09/2021
05/08/2021
10/08/2021
02/08/2021
26/07/2021
26/07/2021
22/07/2021
04/08/2021
05/08/2021
12/07/2021
12/07/2021
12/07/2021
09/07/2021
09/07/2021
17/02/2022
01/07/2021
29/06/2021
07/07/2021
07/07/2021
07/07/2021
07/07/2021
07/07/2021
31/05/2021
08/12/2021
07/07/2021
24/05/2021
12/01/2022
05/05/2021
04/05/2021
04/05/2021
21/04/2021
04/05/2021
04/05/2021
15/04/2021
16/09/2021
15/03/2021
16/02/2021
17/02/2021

17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
07/07/2021
10/02/2021
17/02/2021
10/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
28/01/2021
17/02/2021
17/02/2021
21/01/2021
17/02/2021
21/01/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
17/02/2021
07/09/2020
17/02/2021
17/02/2021
22/06/2020
16/09/2020
06/05/2020
30/03/2020
08/04/2020
10/11/2020
10/02/2020
10/02/2020
07/04/2020
10/02/2020
02/02/2020
02/02/2020
10/02/2020
10/02/2020
10/02/2020

04/02/2020
10/02/2020
29/01/2020
10/02/2020
10/02/2020
03/01/2020
17/02/2021
18/06/2020
10/02/2020
21/10/2019
22/10/2019
22/10/2019
30/09/2019
30/09/2019
30/09/2019
23/09/2019
21/08/2019
05/09/2019
05/09/2019
05/09/2019
28/01/2020
21/08/2019
21/08/2019
21/08/2019
30/09/2019
05/09/2019
21/08/2019
21/08/2019
30/09/2019
05/09/2019
05/09/2019
30/09/2019
05/09/2019
05/09/2019
30/09/2019
30/09/2019
05/09/2019
30/09/2019
25/03/2019
25/03/2019
14/03/2019
30/09/2019
28/02/2019
28/02/2019
21/02/2019
21/02/2019
21/02/2019
21/02/2019

21/02/2019
21/02/2019
21/02/2019
30/09/2019
21/02/2019
21/02/2019
21/02/2019
21/02/2019
20/02/2019
31/01/2019
21/02/2019
21/02/2019
21/02/2019
20/02/2019
20/02/2019
05/05/2020
30/01/2019
30/01/2019
30/01/2019
13/11/2019
21/02/2019
21/02/2019
21/02/2019
30/01/2019
30/01/2019
30/01/2019
30/09/2019
30/01/2019
30/01/2019
04/02/2019
05/09/2018
09/07/2018
30/09/2019
30/01/2019
30/01/2019
05/09/2018
09/07/2018
09/07/2018
05/09/2018
05/09/2018
07/06/2018
10/05/2018
10/05/2018
10/05/2018
10/05/2018
09/07/2018
05/09/2018
10/05/2018

10/05/2018
10/05/2018
10/05/2018
08/06/2020
19/09/2017
19/09/2017
31/08/2017
09/07/2018
30/01/2019
19/09/2017
19/09/2017
19/09/2017
19/09/2017
19/09/2017
19/09/2017
31/08/2017
22/05/2018
30/01/2019
19/09/2017
30/01/2019
30/01/2019
19/09/2017
30/01/2019
19/09/2017
09/01/2017
28/11/2017
09/01/2017
09/01/2017
12/11/2019
07/08/2017
04/05/2016
27/07/2016
28/04/2016
28/04/2016
27/07/2016
27/07/2016
24/01/2017
27/07/2016
19/09/2017
27/07/2016
27/07/2016
27/07/2016
27/07/2016
28/07/2016
22/02/2016
28/07/2016
28/07/2016
01/12/2015

10/12/2015
19/09/2017
28/07/2016
28/07/2016
16/12/2015
28/07/2016
16/12/2015
22/02/2016
16/12/2015
28/07/2016
26/05/2015
25/03/2015
05/05/2015
17/03/2015
25/03/2015
23/02/2015
28/02/2015
26/05/2015
26/05/2015
23/02/2015
28/02/2015
28/07/2016
09/02/2015
03/02/2015
17/03/2015
25/03/2015
07/01/2015
05/05/2015
17/03/2015
26/05/2015
09/09/2014
25/08/2014
17/03/2015
14/08/2014
17/03/2015